

# FlashDrain™ DRAIN BOOT

TPO Low Slope Systems

## OVERVIEW

FlashCo's TPO FlashDrain Drain Boots are Factory Certified prefabricated roof outlet liners that allow free flowing water to exit the roof into a downspout. FlashDrain Drain Boots are constructed from 60 mil reinforced TPO membrane and available in two standard sizes: 2" and 3", each with a depth of 12". Unlike other designs on the market, FlashCo's transition weld does not cause ponding water around the opening. FlashCo's Drain Boots are quick and easy to install. Simply insert the appropriate size flashing into an outlet and weld the flange to the field membrane.

## Custom Sizes and Colors Made to Order

## INSTALLATION

Drain Boots shall be installed in accordance with the recommendations and specifications of the roofing material manufacturer.

1. Prepare all welding surfaces by cleaning with TPO membrane cleaner.
2. Insert appropriately sized Drain Boot into outlet or downspout.
3. Lift flange and heat weld to field membrane, working from center outwards.
4. After the flashing has cooled, probe welds to verify a secure bond.
5. Apply cut edge sealant (provided by others) around edge of base.



## FEATURES AND BENEFITS

- Up to 60% labor savings compared to field fabrication
- Available for NDL and discretionary jobs
- Outperforms other industry designs

## SAVING THE CONTRACTOR TIME

- FlashCo strives to ship 90% of orders within 1-3 days after purchase orders are placed
- All major membrane manufacturer brands in stock in all FlashCo plant locations
- Get off the roof sooner

## STANDARD SIZES & PACKAGING

Description	Outside Dia.	Flange Dia.	Qty./Box	Wt./Box	Box Size
2"	1 7/8"	12"	12	8 lbs.	12"x12"x12"
3"	2 3/4"	14"	12	8 lbs.	12"x12"x12"

Standard depth is 12"

Also available in custom sizes & colors

